

EASY INSTALL Easy mounting of screens





First two brackets are fixed on the wall or ceiling.

Then the screen is inserted in the brackets and

secured with screws. Even large screens can be

Easy and comfortable

easily mounted like this.





Flexible installation

The position of the mounting elements does no longer depend on the width of the screen. The mounting brackets can be fixed on the wall or ceiling in a distance of up to 50 cm from both edges of the screen.

accessories enable every user to install an electrical screen: Just put the plug into the socket of the screen and the cover on the wiring, and the screen

is ready to use.

ccessories for Easy Install screens

Plug & play accessories

The plug & play

Illustration	Model	Specification	Cable length	Ref. No.
	Radio remote control	Plug & play with receiver, 4-channel remote, mains cable with Schuko plug, range up to 30 m	5 m	5944 000 011
	On-wall push button	For radio remote control (5944 000 011) 868.3 Mhz		5944 000 017
87	IR remote control	Plug & play with receiver, remote, mains cable with Schuko plug, range up to 7 m	5 m	5944 000 012
8-3	Relay box	Plug & play, for controlling screens via a media control	5 m	5944 000 014