

Product Warranty Information

Product Name						
Model			Purchase Date			
Distributor Information	Distributor			Telephone		
	Address					
User Information	User			Telephone		
	Address					
Maintenance Records	No	Date	Descriptions	Causes and Solutions	Repaired By	Repair Date
	1					
	2					
	3					



Video Converter User Manual
VGA TO AV


PRODUCT WARRANTY CARD

Warranty Protocol

Thank you for choosing our product. To protect your rights, please read the provisions below carefully, and fill in the contents on the back side.

1. Warranty services refers to the after-sale service provided by our company to our products free of charge and the maintenance service out of warranty period at a reasonable price.
2. If you encounter any quality problem, please contact us with presentation of the Product Warranty Card and valid invoice for maintenance service.
3. Free exchange within 15 days and free maintenance (accessory parts not included) within 1 year after the purchase date, and maintenance service at a reasonable price exceed 1 year after the purchase date.
4. If your problem can't be solved for regular use after our maintenance service for twice, you can choose to get a new one for replacement by presenting your Product Warranty Card with complete maintenance records. Therefore, you are suggested fill in the Product Warranty Card carefully and keep your valid invoice for use.
5. Warranty service will not be available as the following situations:
 - 1) Intentional damages.
 - 2) Damages caused by improper usage, maintenance or storage not in accordance with instructions stated in this User Manual.
 - 3) Without valid product warranty card or valid invoice.
 - 4) Product model number or serial number provided is not the same as that of the product presented.
 - 5) Unauthorized damage or alteration to the Product Warranty Card.
 - 6) Failures caused by the user's maintenance or modification on his own or maintenance performed by people not from our company.
 - 7) Failures or damages caused by force majeure.
 - 8) Exchange or exchange is not applicable if obvious scratches or defects in product surface are found, however free maintenance is provided. Refund or exchange for a whole machine is only for machines with good appearance and package without any missing accessories.
6. This Product Warranty Card is invalid in duplication.
7. This Product Warranty Card is invalid with alteration, No reissue if losing so please keep it well.

Connection Sketch of Video Converter



Thank you for choosing our video converter. We hope this product could bring you a perfect visual experiences. Before using it, please read this manual carefully for your better knowledge of all the functionalities of this converter.

© Copyright by the manufacturer, all rights Reserved.

Exemption Declaration

Manufacturer bears no any compensation responsibilities for any loss resulted from any misuse of the product mentioned in this manual and he fails to operate or use in accordance with the instructions stated below.

The manufacturer reserves the rights to modify the product or its system mentioned herein from time to time to improve its reliability, functionalities or designs without prior notification.

The manufacturer reserves the rights of final interpretation of this manual.

Contents

I. Introduction.....	P2
II. Performance Features.....	P2
III. Product Parts List.....	P3
IV. Sketch Map.....	P3
V. Ports Description.....	P4
VI. Installation and Settings.....	P4
VII. Trouble Shooting.....	P5

4. Interference in display

This may be caused by insufficient power supply from USB part, try an external 5V power supply. It may also result from the close placement with Machines which can produce magnetic field, move the converter away to see if the display is improved.

5. Wry pictures.

Check to see if the PC's resolution degree and vertical frequency are supported by this converter, and also you can try to change the PC's refresh frequency to see if it Works.

6. Hems of the PC screen not displayed on TV or black hems found along TV screen.
Press MENU/RESET +FREEZE at the same time, then release.

3. OSD.



VII. Troubleshooting

1. No picture displayed.
Make sure the cables are correctly connected, and check to see if the output end and input end are reversed. Also make sure power cable is connected well.
2. No AV displayed.
Check to if the AV cable is in good condition and correctly connected. And if it's ok, check to see if the display terminal and TV set etc is switched to AV mode.
3. No S-VIDEO displayed.
Check to see if the S-VIDEO cable is in good condition and correctly connected.
And if OK, check to see if video output equipment is switched to S-VIDEO mode.

I. Introduction

Computer screens can be transmitted and displayed on TV by using this video converter. The picture definition can be as high as that of pictures played by DVD machines. It is suitable for business briefing, multi-media education, video play for sales promotion, computer games, etc. It supports plug-and-play, no driver program installation is needed. Its mini size enables nice portability. (Product size customization is supported by the manufacturer if the order quantity is reasonably big enough).


II. Performance Features

1. Supported VGA resolution: 640x 480 @ 60/72/75/85 Hz, 800x600 @60/75 Hz, 1024x768 @60Hz /75Hz, 1280x768@60Hz, 1280x1024@60Hz.
2. Simultaneous output of VGA, VIDEO and S-VIDEO signals.
3. Synchronous display of pictures on both the computer monitor and the TV display.
4. Power supply from the USB ports (and power transformer can be used when current is not enough from USB ports)
5. Both PC and MAC machines supported.
6. Both PAL system and NTSC system supported.
7. Light, thin, short, small for good portability.

III. Product Parts List

Parts Name	Quantity	Notes
Video converter	1	
USB power supply cable	1	To be connected to PC USB port.
User manual	1	

IV. Sketch Map



V. Ports Description (refer to the sketch in Section IV)

- VGA IN.....to PC graphic card
- VGA OUT.....to PC monitor
- S-VIDEO OUT.....to TV set /video tape recorder
- VIDEO OUT.....to TV set /video tape recorder
- Power 5V/1A.....to 5V/1A power supply

VI. Installation and Settings

1. Get the product well connected according to “Connection Sketch of Video Converter” on Page 7.
2. Adjust the picture quality and the signal system.

← Picture upward ↓ Picture Downward ↑ Picture leftward → Picture Rightward

MENU.....Press for OSD menu.

ZOOM.....Press to magnify the screen, twice press to come back.

System Shift.....PAL when both up and NTSC when both down.